

Experiment - 2

Objective: To determine the resistivity of given sample using four probe method.

Apparatus: Digital Ammeter, voltmeter, probes, dc current source.

Formula Used:  $\rho = 2\pi S \frac{V}{I}$   $S \rightarrow$  probe spacing  
 $\rho = \rho_0 Q$   $Q \rightarrow$  correlation fn which corrects for finite thickness of sample.

Result: from the graph :

$$R = 58 \Omega$$

and

$$\rho = 84.91 \Omega \text{ cm} \quad \rho_0 = 10.61 \Omega \text{ cm}$$

Precautions:

- 1) Surface of sample used should be flat.
- 2) All four probes should be collinear.
- 3) Voltage should be measured using four probes only.

Teacher's Signature \_\_\_\_\_

Dr. Anand  
102003253

Objective: To determine the resistivity of given sample using four probe method.

Apparatus: digital ammeter, voltmeter, probes, dc current source.

Formula used:  $\rho = 2\pi S V/I$  ;  $\rho = \rho_0 / G$

Observations and Result: In our experimental setup,

$$S = 0.233 \text{ cm}$$

$$b = 0.04 \text{ cm}$$

$$b/s = 0.172 \quad \text{so, } G(b/s) = G(0.172) = 8$$

$I(\text{mA})$	$V(\text{mV})$
1	61
2	122
3	181
4	239
5	300
6	359
7	418
8	475
9	531
10	583

$$R = \frac{V_{10} - V_1}{I_{10} - I_1}$$


$$= \frac{583 - 61}{10 - 1}$$

$$= \frac{522}{9} = 58 \Omega$$

$$\rho_0 = 2\pi S R = 84.91 \Omega \text{ cm}$$


$$\rho = \rho_0 / G = 10.6 \Omega \text{ cm}$$

Diagram:



manip...





drawn by